

Toestel	4G Bellen	WiFi Bellen
Alcatel A3 / U5	✓	✓
ASUS ROG Phone	✓	✓
BlackBerry KEY2	✓	✗
Cat B35	✓	✗
HTC U11 (Vodafone software)	✓	✗
Huawei Mate 10 Pro	✓	✓
Huawei Mate 20 (ook Pro en Lite)	✓	✓
Huawei P Smart 2018 & 2019	✓	✓
Huawei P10 (ook de Plus en Lite)	✓	✓
Huawei P20 (ook Pro en Lite)	✓	✓
Huawei P30 (ook Pro en Lite)	✓	✓
iPhone 5S & 5C	✗	✓
iPhone 6 / 6S / 7 & 8 (ook de Plus)	✓	✓
iPhone X / Xs / Xs Max & SE	✓	✓
Motorola G7 (ook de Power en Play)	✓	✓
Motorola G7 Plus	✓	✗
Nokia 1 / 2 / 3 / 3.1 & 5	✓	✗
Nokia 7 Plus & 7.1	✓	✓
Nokia 8 (ook de Sirocco)	✓	✗
Nokia 8.1 & 8110 4G	✓	✗
Nokia 9 PureView	✓	✓
Samsung A3 & A5 (2016 en 2017)	✓	✓
Samsung A6 & A7	✓	✓
Samsung A20e / A40 / A50 & A70	✓	✓
Samsung A8 (2018) & A9	✓	✓
Samsung J3 2017 / J5 (2017)	✓	✓
Samsung J4+	✓	✓
Samsung J6 (2018) / J6+ (2018)	✓	✓
Samsung Note 8	✓	✓
Samsung S6 / S7 (Flat en Edge)	✓	✓
Samsung S6 Edge Plus	✓	✓
Samsung S8 & S8+	✓	✓
Samsung S9 / S9+ / Note 9	✓	✓
Samsung S10 / S10+ / S10e	✓	✓
Samsung Xcover 4	✓	✓
Sony Xperia XA2	✓	✗
Sony Xperia 10 (ook bekend als XA3)	✓	✓
Sony Xperia XZ2 / XZ2 Compact / XZ3	✓	✓
Wiko View2	✓	✗

✓ = geschikt.

✗ = (nog) niet geschikt.